



ENGLERT®

<http://www.englertinc.com>

SLOPE FACTORS

When Scaling A Roof Size From A Drawing,
Multiply Roof Area x Slope Factor = Total Area

2/12	Roof Area x 1.0147	=	Total Area
3/12	Roof Area x 1.031	=	Total Area
4/12	Roof Area x 1.054	=	Total Area
5/12	Roof Area x 1.083	=	Total Area
6/12	Roof Area x 1.118	=	Total Area
7/12	Roof Area x 1.158	=	Total Area
8/12	Roof Area x 1.202	=	Total Area
9/12	Roof Area x 1.250	=	Total Area
10/12	Roof Area x 1.302	=	Total Area
11/12	Roof Area x 1.357	=	Total Area
12/12	Roof Area x 1.413	=	Total Area

Contact the Englert Customer Value Center at 1-800-ENGLERT
(1-800-364-5378) for more information and assistance.